
Cable Carriers - Low Particle Generation, Low Noise



Part Number		Bending	Number	Mounting	Cable Carrier Dimensions					Mounting Dimensions										Н		HF	K	Weight per		
Type	No.	Radius O Selection	of Links	Direction	Α	В	С	w	Р	l	F	т	J	х	D	Applicable Screw (D)	P1	P ₂	Рз	P4	P 5	(Mounting Ha	H ₁	(Required Physical Height)	(Arc + Margin)	Meter (kg) (Reference)
	1520	28	8~67		15	٥٢	20	00	10	29	200	10	20.0	20.4	4.0	M4	12	15	8	8	3	95	70	115	128.6	0.34
MPSCS (Cable Carrier + Mounting Brackets)	1520	34	9~68	ı	15	25	5 20	28	18	29	22 1	10	32.8	32.8 30.4	4.2	IVI4	12	15				105	80	125	144.3	0.34
	2040	31	8~77	S (Common to Mounting on the	20									1.8 52.4					1			115	82	145	150.4	
		38	9~78			33	40	50 2	20	35	26	14	54.8		6.5	M6	21	27				130	97	160	174	0.7
		58	12~81																			170	137	200	236.8	
	2540	60	9~57			40	40	50	20	52 E			56.4	53.2		M6	21	40	1			185	145	215	251.5	0.77
		85									40				7	IVIO	21	40] _ [١.	235	195	265	330	0.77
	2560	60			25	40	60	70	30	52.5		l L	76.4	73.2	ı ′	M6	35.4	47			-	185	145	215	251.5	0.94
	2580	60	9~57		25	40	80	90	30	52.5			96.4	93.2	3.2	M6	60	75.2]			185	145	215	251.5	1.2
	3560	75	8~51							68.5					-	-	-	-				240	185	270	323.9	1.4
		100	10~53		33	55	00	13	45			_										295	240	325	410.2	1.4
	35100	75	8~47	:	25	55	100	112	45	68.5	- 1	_										240	185	270	323.9	2
		100	10~49		33	33	100	113	45													295	240	325	410.2	2

Part Number Type No.		Bending	Number		Unit Price	Mounting Direction				
		Radius Selection	of Links	Mounting Direction	Cable Carrier + Mounting Bracket (One Link Unit Price x Number of Links) + Mounting Bracket Price	For Moving Ends				
MPSCS (Cable Carrier + Mounting Brackets)	1520	28	8~67			Mounting on the Outer Circumference				
	1320	34	9~68	S						
		31	8~77			(20-10-10)				
	2040	38	9~78							
		58	12~81			(e)				
	2540	60	9~57							
	2040	85	11~60	(Common to Mounting on the Outer and Inner		For Fixed Ends				
	2560	60	9~57	Circumferences)		Mounting on the Outer Circumference Mounting on the Inner Circumference				
	2580	60	9~57			Mounting on the outer circumference Mounting on the liner circumference				
	3560	75	8~51							
	3300	100	10~53			(0-(0-(0)))				
	35100	75	8~47							
	30100	100	10~49							

<Cautions on Model Selection>

A Cable Carrier and suitable Mounting Brackets (Moving Ends x1 set, Fixed Ends x1 set) are in a set.





In the case of new designs, there may be a possibility that carrier links

It is recommended that links are selected longer by one or two links, and are adjusted (removed) at the time of installing (removing) device.



■Low Particle Generation, Low Noise Cable Carriers (MPSCS) - Link Connection






Align cable carrier connection pins with the connection holes. Be sure to keep clear of the twist prevention stopper when fitting them together.



2 Insert the cable carrier in the main body Be sure that the connection plate is fully mated with the cable carrier



Fixing Hook for Joint Part 3Insert joint parts Insert the joint part into the cable carrier to align joint part connection holes with the connection pins.



4 Confirm the connection Please be sure if there is no gap between the joint parts and the cable carrier, and if the joint parts mounting hooks are secure